



## OXYGEN & ACETYLENE HOSE FITTINGS & CONNECTORS (Brass)

### ADAPTORS



OXYGEN



ACETYLENE

Straight Thread Both Ends

PART NO.	THREAD SIZE	HEX SIZE
4ADR	9/16-18 R.H. to 9/16-18 R.H.	9/16
4ADL	9/16-18 L.H. to 9/16-18 L.H.	9/16

### Male HOSE STEMS



OXYGEN



ACETYLENE

OXYGEN STEM R.H. THREAD	ACETYLENE STEM L.H. THREAD	THREAD SIZE	HOSE I.D.
12MR	12ML	9/16-18	1/4

### OXYGEN & ACETYLENE NUTS

OXYGEN



OXYGEN R.H. THREAD	ACETYLENE L.H. THREAD	THREAD SIZE
160D	160E	9/16-18
155D	155E	3/8-24

ACETYLENE



### HOW TO ORDER

Detailed and cut-away illustrations of all Lenz parts are clearly shown with part numbers and complete specifications for your convenience in ordering.

**HOSE ASSEMBLIES:** When giving a hose assembly part number, add the desired overall assembly length in inches to complete the part number. Example: To part number CL-4-44 add the overall assembly length (O.A.)...CL-4-44-18" for a 1/2" Male Pipe to 1/2" Union Female Pipe, 1/2" 2 BSR Hose and O.A. length of 18".

If hose ends have pipe threads of different sizes such as 1/4" Male Pipe one end and 3/8" Male Pipe on the other end of 1/4" 2BSR Hose, the assembly number would be AL2-32-O.A.

On hose assemblies with Union on one end, indicate which pipe size is to be union by spelling out.

**HOSE LENGTHS:** Order bulk hose in feet. Specify random or cut lengths. 1 and 2 BSR Hose are available up to 50 feet lengths, 1 1/2 FTR Multi-Purpose Hose up to 250 feet lengths.

### HOW TO ASSEMBLE LENZ LOW PRESSURE HOSE FITTINGS



1. Place Ferrule Over Hose End and oil inside of hose.



2. Oil stem thread and place stem in Ferrule.



3. Screw Stem Down.



4. Completely Assembled.

**BACK TO**

**CATALOGUE**

## ADAPTORS



OXYGEN



ACETYLENE

### Straight Thread Both Ends

PART NO.	THREAD SIZE	HEX SIZE
4ADR	9/16-18 R.H. to 9/16-18 R.H.	9/16
4ADL	9/16-18 L.H. to 9/16-18 L.H.	9/16

## Male HOSE STEMS



OXYGEN



ACETYLENE

OXYGEN STEM R.H. THREAD	ACETYLENE STEM L.H. THREAD	THREAD SIZE	HOSE I.D.
12MR	12ML	9/16-18	1/4

## OXYGEN & ACETYLENE NUTS

OXYGEN



OXYGEN R.H. THREAD	ACETYLENE L.H. THREAD	THREAD SIZE
160D	160E	9/16-18
155D	155E	3/8-24

ACETYLENE



## HOW TO ORDER

Detailed and cut-away illustrations of all Lenz parts are clearly shown with part numbers and complete specifications for your convenience in ordering.

**HOSE ASSEMBLIES:** When giving a hose assembly part number, add the desired overall assembly length in inches to complete the part number. Example: To part number CL-4-44 add the overall assembly length (O.A.)...CL-4-44-18" for a 1/2" Male Pipe to 1/2" Union Female Pipe, 1/2" 2 BSR Hose and O.A. length of 18".

If hose ends have pipe threads of different sizes such as 1/4" Male Pipe one end and 3/8" Male Pipe on the other end of 1/4" 2BSR Hose, the assembly number would be AL2-32-O.A.

On hose assemblies with Union on one end, indicate which pipe size is to be union by spelling out.

**HOSE LENGTHS:** Order bulk hose in feet. Specify random or cut lengths. 1 and 2 BSR Hose are available up to 50 feet lengths, 1 1/2 FTR Multi-Purpose Hose up to 250 feet lengths.

## HOW TO ASSEMBLE LENZ LOW PRESSURE HOSE FITTINGS



1. Place Ferrule Over Hose End and oil inside of hose.



2. Oil stem thread and place stem in Ferrule.



3. Screw Stem Down.



4. Completely Assembled.

**BACK TO**

**CATALOGUE**